# Logomark
Different by design

Right read - Side below clip (standard)

Left read - Side below clip (optional)