

Care Instruction for Wood Cheese Set

1. Use hot water and a small amount of mild dish soap, and gently scrub in circular motions with a soft sponge. Do not soak the board in water. The board should be protected against excessive water absorption which can lead to cracking or warping of the board.
2. Rinse the wood board under warm water to get all the soap and remaining residue off the wood.
3. Wipe the wood with a dry cloth or paper towel.
4. To disinfect, make a 2:1 mixture of water and vinegar and apply to both sides. Let sit for a few minutes and rinse with water. Follow points 2 and 3 to rinse and dry the wood after disinfection.
5. To deodorize, make a thick paste combining 1 cup of baking soda and 2 tablespoons of water and smear it all over the board. Let it sit, then pour white vinegar over the board to remove the mixture. Follow points 2 and 3 to rinse and dry the wood after deodorizing.