

# MULTI-FUNCTION CLOCK MANUAL

## A. FEATURES

1. Time display of month, date of-week, hour.
2. Alarm function
3. User' s selectable 12-Hour/24-Hour format.

## B. ALARM TIME SETTING MODE

Press "SET" key to enter "ALARM TIME SETTING" mode

Press "UP" key to advance the hour display

Press "MODE" key to finish the Hour setting and use "UP" key to advance Min display

## C. TIME/CALENDAR SETTING MODE

Press "SET" key 2 time to enter TIME / CALENDAR setting mode

Press "UP" key to advance Hour display

Press "MODE" key to finish Hour setting and use "UP" key to advance Minute display

Press "MODE" key to finish Minute setting and use "UP" key to advance Month display

Press "MODE" key to finish Month setting and use "UP" key to advance Date display

Press "MODE" key to finish Date setting and use "UP" key to advance Year display

Press "SET" key to return to NORMAL display mode

## D. ALARM FUNCTION

When time display is in NORMAL mode

Press "MODE" key to enable or disable the alarm function

## E. 12 HOUR / 24 HOUR FORMAT

When time display is in NORMAL mode

Press "UP" key to change 12 /24 hour format