iCOOL

GL2020 Tactical Flashlight

Instruction Manual





1 x Flashlight / 3 x AAA 1.5V Battery

Specification:

- 1 500 Lumens
- 2. Usage Time when Fully Charged -
- High Mode 2 Hours
- Low Mode 4.5 Hours

Operation:

- 1. Unscrew the end-cap battery cover. Remove the battery holder and insert 3 x AAA batteries into the holder following the "+" "-" polarity markings.
- 2. Replace the battery holder with the "+" side toward the head of the flashlight, and screw the cover back on. Note: To avoid injury, do not use any other battery type/s.



- 3. Soft Press On/Off Button to cycle through modes while light is on:
- Press 1x High Mode / Press 2x Off / Press 3x Low Mode / Press 4x Off / Press 5x -Flash Mode / Press 6x - Off
- 4. Extend the flashlight head for zoom function.

Caution & Safety:

- Do not expose the flashlight to moisture, sunlight, or other heat sources.
- Do not direct the beam towards people or animals even from distances.
- Keep away from children.
- Battery must be recycled and disposed of properly.
- Operation temperature range between 32°F and 113°F.

FCC Part15:

CAUTION: Risk of fire and burns. DO NOT open, crush, heat above 45°C / 113° for incinerate Follow Manufacturer's instruction

ATTENTION: Risque d'incendie et de brúlures. Ne pas incinerer, ouvrir ou endommager. ne pas exposer á une chaleur au-dessus de

45°C/113°F Merci de suivre. Les instructions du fabricant.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: . 1) this device may not cause harmful interference, and (2) this device must accept any interference eceived, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the ECC Rules. These limits are designed to provide reasonable protection against harmful nterference in a residential installation.

IMPORTANT SAFFTY INSTRUCTIONS

WARNING - When using this product, basic precautions should always be followed, including the following: Read all the instructions before using the product.

- To reduce the risk of injury, close supervision is necessary when the product is used near children. . Do not put fingers or hands into the product.
- Do not expose the product to rain or snow.
- Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or injury to persons. • Do not use the product in excess of its output rating. Overload outputs above rating may result in a risk of
- fire or injury to persons. • Do not use the product that is damaged or modified. Damaged or modified batteries may exhibit
- unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
- Do not expose the product to fire or excessive temperature. Exposure to fire or excessive emperature may cause an explosion.

FRONT

BACK